





The shoulder belt **MUST** lay across child's shoulder in the red zone as shown. If the shoulder belt lays outside this zone, the shoulder belt positioning clip **MUST** be used.




Insert the loop end of the strap around the middle of the strap on the underside of the BubbleBum as shown in diagram A.



Pass the clip through the loop ends (like a luggage label) as shown in diagram B and pull straps as shown in diagram C.



Slide the vehicle belt into the clip as shown in diagram D and pull down to tighten clip against child's shoulder. The lap belt portion **MUST** pass through both red side clips and be positioned low on the hips. The belt **MUST NOT** be twisted.



Securing Child in Vehicle with Shoulder Belt Positioning Clip

- Remove BubbleBum from bag and locate air valve at rear of BubbleBum. Twist to open and blow into valve until it reaches maximum capacity, then twist to close. (image 1)
- Position child on BubbleBum in vehicle, THEN buckle vehicle seat belt. (image 2)
- Pinch the lapbelt (image 3) and slot into BOTH red side clips on either side of the seat. (images 4 and 5)
- Seat belt straps should fit firmly against the child and lap straps should be worn low down across the child's lap. Ensure straps are not twisted.
- To remove, pinch the vehicle belt at the red side clip nearest the buckle (image 3) and remove. THEN unbuckle the vehicle seat belt.
- For storage, place on a flat solid surface with valve facing away from you and roll to expel air. Repeat this step twice to remove as much air as possible and then close valve before packing in the bag provided. (image 6)

Remember: The side clips are much easier to install and uninstall when the vehicle seat belt is buckled.

User instructions